

TOOL MODEL XLCTI-2(S19~S55)



PRESSURE/TORQUE CONVERSION CHART

Standard Torque Chart

PRESSURE IN PSI	TORQUE IN NM
1200	275
1400	321
1600	367
1800	413
2000	458
2200	504
2400	550
2600	596
2800	642
3000	688
3200	734
3400	779
3600	825
3800	871
4000	917

PRESSURE IN PSI	TORQUE IN NM
4200	963
4400	1009
4600	1054
4800	1100
5000	1146
5200	1192
5400	1238
5600	1284
5800	1329
6000	1375
6200	1421
6400	1467
6600	1513
6800	1559
7000	1605

PRESSURE IN PSI	TORQUE IN NM
7200	1650
7400	1696
7600	1742
7800	1788
8000	1834
8200	1880
8400	1925
8600	1971
8800	2017
9000	2063
9200	2109
9400	2155
9600	2201
9800	2246
10000	2292