

TOOL MODEL XLCTI-4(S46~S65)



PRESSURE/TORQUE CONVERSION CHART

Standard Torque Chart

PRESSURE IN PSI	TORQUE IN NM
1200	692
1400	808
1600	923
1800	1039
2000	1154
2200	1269
2400	1385
2600	1500
2800	1616
3000	1731
3200	1846
3400	1962
3600	2077
3800	2193
4000	2308

PRESSURE IN PSI	TORQUE IN NM
4200	2423
4400	2539
4600	2654
4800	2770
5000	2885
5200	3000
5400	3116
5600	3231
5800	3347
6000	3462
6200	3577
6400	3693
6600	3808
6800	3924
7000	4039

PRESSURE IN PSI	TORQUE IN NM
7200	4154
7400	4270
7600	4385
7800	4501
8000	4616
8200	4731
8400	4847
8600	4962
8800	5078
9000	5193
9200	5308
9400	5424
9600	5539
9800	5655
10000	5770